This Information Is Provided By

CBTricks.com

How to install the Powerband RFX75 & RFX85 on Cobra 25 series radios.

Liability of damages to any equipment is the sole responsibility of the user!

Downloading, viewing, or using any information provided on these pages automatically accepts the user to the terms of this agreement!

Modifications are provided for information purposes only!

Supporters of CBTricks.com paid for the hosting so you would have this file.

CBTricks.com is a non-commercial personal website was created to help promote the exchange of service, modification, technically oriented information, and historical information aimed at the Citizens Band, GMRS (CB "A" Band), MURS, Amateur Radios and RF Amps.

CBTricks.com is not sponsored by or connected to any Retailer, Radio, Antenna Manufacturer or Amp Manufacturer, or affiliated with any site links shown in the links database. The use of product or company names on my web site is not endorsement of that product or company.

The site is supported with donations from users, friends and selling of the Site Supporters DVD's to cover some of the costs of having this website on the Internet instead of relying on banner ads, pop-up ads, commercial links, etc. Thus I do not accept advertising banners or pop-up/pop-under advertising or other marketing/sales links or gimmicks on my website.

All the money from donations is used for CBTricks.com I didn't do all the work to make money (I have a day job). This work was not done for someone else to make money also, for example the eBay CB sellers.

All Trademarks, Logos, and Brand Names are the property of their respective owners. This information is not provided by, or affiliated in any way with any radio or antenna Manufacturers.

Thank you for any support you can give.

For information on how to Support CBTricks.com http://www.cbtricks.com/support/

The user is solely responsible for making sure that any modifications made to the radio unit must meet all Federal and State Regulations or the Country of use! Liability of damages to any equipment is the sole responsibility of the user! Downloading, viewing, or using any information provided on these pages automatically accepts the user to the terms of this agreement! Modifications are provided for information purposes only! Disclaimer: CBTricks.com does not warrant the accuracy of the information contained herein nor is it responsible for any errors or omissions and assumes no liability for the content on this site. While CBTricks.com uses reasonable efforts to include accurate and up to date information, CBTricks.com makes no warranties or representations as to its accuracy or timeliness and assumes no liability or responsibility for any errors or omissions in the content of this site.


RFX75 and RFX85 – Cobra 25 Installation

- 1. Remove L9, R40, C1, C41, C149, and the final transistor from the Cobra 25.
- 2. Remove L8 from Cobra 25 and install a jumper wire in its place.
- 3. In Cobra 25, solder one lead of a 12pF 15pF ceramic disc capacitor at solder pad junction of D1 and C4 and solder the other capacitor lead to jumper wire at L8.
- 4. Remove the capacitor at C10 and the Blue wire on the RFX75 or RFX85.
- 5. Remove the Yellow wire from the RFX75 or RFX85
- 6. Remove the RX OUT coax from the RFX75 (RX OUT not on RFX85)
- 7. Drill and mount the RFX unit to the rear panel of the radio.
- 8. Solder the RF IN coax center conductor to the hole of R40 that is closest to the front panel of the radio. Solder the shield to DC ground.
- 9. Solder the RF OUT coax center conductor to the back of the antenna connector's center pin. Solder the coax shield to the tab that is Chassis ground on the antenna connector.
- 10. Solder the Orange wire to the side of L11 that is closest to the front panel of the radio.
- 11. Replace R53 with a 470K ohm, ¹/₄ watt resistor. R53 is located near the audio amp IC.
- 12. After re-tuning the radio, verify that the carrier is not higher than 15 watts.

If the carrier is higher than 15 watts, perform the following steps.

- a. Remove JP6 and install a $1000\mu F$, 16 volt electrolytic capacitor with the negative lead of the capacitor towards the back of the radio.
- b. On the back of the PCB, Install a 10ohm to 33ohm ¼ watt resistor across the two points of JP6 to obtain the desired carrier level. Typically, a 15 ohm ¼ watt resistor is about right.

If the carrier is lower than the desired amount, you can add a 68pF ceramic disc capacitor across C46. This will increase the carrier slightly.



The user is solely responsible for making sure that any modifications made to the radio unit must meet all Federal and State Regulations or the Country of use! Liability of damages to any equipment is the sole responsibility of the user! Downloading, viewing, or using any information provided on these pages automatically accepts the user to the terms of this agreement! Modifications are provided for information purposes only! Disclaimer: CBTricks.com does not warrant the accuracy of the information contained herein nor is it responsible for any errors or omissions and assumes no liability for the content on this site. While CBTricks.com uses reasonable efforts to include accurate and up to date information, CBTricks.com makes no warranties or representations as to its accuracy or timeliness and assumes no liability or responsibility for any errors or omissions in the content of this site.